


Drawing a rectangular Polyline:

Method 1:

1. Select the **Rectangle** symbol  from the draw menu.
2. Specify on the screen the first corner for the rectangle you want to draw.
3. Type **D** to specify the dimension for the rectangle.
4. Input the length.
5. Input the width.
6. Click anywhere inside the rectangle area to get out of the command.

Method 2:

1. Type **RECTANG** or **REC** in the command line.
2. Specify on the screen the first corner for the rectangle you want to draw.
3. Type **D** to specify the dimension for the rectangle.
4. Input the length.
5. Input the width
6. Click anywhere inside the rectangle area to get out of the command.

If you need any further help, contact me using the [contact page](#) or visit the discussion forum site <http://www.2learncad.com/forum>.